

DECAL INSTALLATION GUIDE



Installation guide for self adhesive decals.

Items needed

- Fill spray bottle with water and small dip of dishwashing liquid
- Microfibre or other soft cloth
- Thin string

Installation

1. Clean your hands.
2. Clean the area of the frame you will install the decal.
3. Spray the section of the frame with the detergent solution generously.
4. Peel the backing paper from the decal exposing the adhesive surface.
5. Spray the adhesive side of the decal with the detergent solution.
6. Position the decal to the frame. The wet film of detergent solution enables to slide the decal into the right position. Use the thin string as plumb line while positioning.
7. When you are satisfied with the position of the decal use the cloth to remove the detergent solution and air bubbles. Start from the center of the decal and work outward. Raise up pressure until all liquid and bubbles are removed.
8. If your decal has been delivered on transfer paper, wait 20-30 minutes before you remove it.
9. Done

Note

The decal adhesive reaches full tack after 24 hours drying time.

If you plan to clear coat your decal wait at least 24h.
Laminated decals do not need to be clear coated.

If you apply the decal to a new painted frame,
make sure the paint is fully dried and will not outgas.